


Shot peening

After coiling, a spring contains stresses at the wire surface on the inside diameter of the spring. For dynamic loaded springs, these stresses do not allow the material properties to be fully exploited. By shot peening the spring, i.e. bombarding the spring with small, round, steel balls, the following improvements with regard to fatigue strength can be achieved:

- Tension in the surface
- Reduction of notch fatigue factor as any small surface defects are closed up.
- Harder surface finish due to cold working by peening.

By shot peening, the life of the spring can be increased by more than 100%. Conversely, an increase in performance of up to 50% can be achieved with the same life. We particularly recommend this method of treatment for compression springs which are exposed to fatigue, where long life is required.



Breaking strength

This diagram is used to check that a compression spring will not break.

Values below curve B: No risk of breakage


Values between curves A and B: The spring should have internal location plus ground ends.

Values above curve A: There is a risk of breakage. The spring should have internal location.

Close coiled extension and torsion springs are not normally shot peened, due to the practical difficulties (limited space for the shot inside the spring). Also, the advantages cannot be realized, compared with compression springs. Generally, compression springs should have a wire diameter of at least 1.5 mm. For thinner wire diameters, the effect is lower and there is a further risk of deformation.

Pre-setting

Pre setting is a plastic deformation, which is accomplished by loading the spring beyond the actual working range. In this way, tension in the surface is obtained in the opposite direction to the load tension. This leads to non or strongly reduced setting when the spring is working. We recommend pre-setting for highly stressed springs. Normally, pre-setting is carried out cold. Springs working in increased temperatures should be pre-set warm.



Coil counting

This figure shows how the total number of coils (n_t) is counted. In this case, it is n_t 10. The number of active coils (n_v) is $n_t - 1.5$.